



International Space Station Ground Handbook Specific ISS-3A

**Mission Operations Directorate
Operations Division**

**Final
June 13, 2000**

*These procedures are available
electronically on the SODF Homepage
at <http://fitproc.jsc.nasa.gov>*

National Aeronautics and
Space Administration

Lyndon B. Johnson Space Center
Houston, Texas



United Space Alliance

**INTERNATIONAL SPACE STATION
GROUND HANDBOOK - SPECIFIC
ISS-3A**

FINAL
June 13, 2000

APPROVED BY:

Brenda Tracy
Book Manager

Michael T. Hurt
Supervisor, Procedures and Portable Computing Section

Kent H. Adams
3A SODF Coordinator

ACCEPTED BY:

Michael T. Hurt
SODF Manager

This document is under the configuration control of the Systems Operations Data File Control Board (SODFCB).

Incorporates the following:	
CR:	U_140 U_144

**INTERNATIONAL SPACE STATION
GROUND HANDBOOK - SPECIFIC**

LIST OF EFFECTIVE PAGES

FINAL 13 JUN 00

Sign Off	13 JUN 00	39	02 DEC 99
ii	13 JUN 00	40	02 DEC 99
iii	13 JUN 00	41	02 DEC 99
iv	13 JUN 00	42	02 DEC 99
v	13 JUN 00	43	12 JUN 00
vi	13 JUN 00	44	12 JUN 00
1	12 JUN 00	45	12 JUN 00
2	12 JUN 00	46	12 JUN 00
3	16 APR 00	47	12 JUN 00
4	16 APR 00	48	12 JUN 00
5	16 APR 00		
6	16 APR 00		
7	16 APR 00		
8	16 APR 00		
9	16 APR 00		
10	12 JUN 00		
11	12 JUN 00		
12	12 JUN 00		
13	02 DEC 99		
14	02 DEC 99		
15	02 DEC 99		
16	12 JUN 00		
17	02 DEC 99		
18	02 DEC 99		
19	24 MAY 00		
20	24 MAY 00		
21	02 DEC 99		
22	02 DEC 99		
23	12 JUN 00		
24	12 JUN 00		
25	02 DEC 99		
26	02 DEC 99		
27	02 DEC 99		
28	02 DEC 99		
29	02 DEC 99		
30	02 DEC 99		
31	02 DEC 99		
32	02 DEC 99		
33	02 DEC 99		
34	02 DEC 99		
35	02 DEC 99		
36	02 DEC 99		
37	02 DEC 99		
38	02 DEC 99		

This Page Intentionally Blank

CONTENTS

<u>C&DH PROCEDURES</u>	1
<u>CORRECTIVE PROCEDURES</u>	
C&DH RECONFIGURE FOR NODE 1 MDMs.....	3
<u>MCS PROCEDURES</u>	11
<u>NOMINAL PROCEDURES</u>	
ACS PRE-ARRIVAL MODING	13
ACS ARRIVAL MODING.....	17
ACS DEPARTURE MODING	19
ACS POST DEPARTURE MODING	21
<u>S&M PROCEDURES</u>	23
<u>ACTIVATION AND CHECKOUT PROCEDURES</u>	
NODE 1 FORWARD CBM CPA CHECKOUT	25
<u>TCS PROCEDURES</u>	43
<u>NOMINAL PROCEDURES</u>	
PMA 3 HEATER CHECKOUT	45

This Page Intentionally Blank

C&DH PROCEDURES

This Page Intentionally Blank

C&DH RECONFIGURE FOR NODE 1 MDMs

(GND/2A.2A - 3A/FIN A)

Page 1 of 7 pages

NOTE

1. This procedure is used to reconfigure the Node 1 MDMs after an Auto Retry Condition has occurred where the Auto Retry function reconfigures the MDMs back to the nominal states of N1-2 Primary and N1-1 Secondary.
2. N1-2 recovered: perform steps 1, 2, and 3.3
N1-1 recovered: perform steps 1 and 3

PCS2

1. VERIFYING MDM STATES

Node 1: C&DH: MDM N1-2

Primary NCS MDM Node 1

Verify Frame Count – <incrementing>

Verify MDM ID – N1-2

Verify MDM State – Primary

Node 1: C&DH: MDM N1-1

Secondary NCS MDM Node 1

Verify Frame Count – <incrementing>

Verify MDM ID – N1-1

Verify MDM State – Secondary

Verifying RS State

If NCS interface is SM Central Computer

sel SMCC Control

Primary NCS SMCC Control

Verify SMCC Frame Count – <incrementing>

If NCS interface is FGB

FGB: C&DH: FGB MDM 2(1)

FGB MDM

Verify FGB Frame Count – <incrementing>

2. RECONFIGURING THE NODE 1-2 MDM

PCS

2.1 Clearing MDM BST Error Latch

Node 1: C&DH: MDM N1-2

Primary NCS MDM Node 1

'Software Control'

sel MDM Utilities

'Clear Latched Data in BST A'

cmd Clear Execute

C&DH RECONFIGURE FOR NODE 1 MDMs

(GND/2A.2A - 3A/FIN A)

Page 2 of 7 pages

<Cmd Inv: Prim_NCS_Clr_Lat_Data – (M1DD95SM1027K)>

Primary NCS MDM Node 1

sel MDM BIT States

√BST Errors – blank
(errors cleared)

PCS2

2.2 Configuring MDM Heaters Controlled by the N1-2 MDM

Node 1: C&DH: MDM N1-2

Primary NCS MDM Node 1

'RPCM N1RS2 C'

√RPC 4 Position – CI

If Open
sel RPC 4

RPCM_N1RS2_C_RPC_4

cmd Close

<Cmd Inv: RPCM_N1RS2_C_RPC_4_N1_1_MDM_SDO_1B_CI –
(M1PR95SM1598K)>

√RPC 4 Position – CI

'N1-1 Heaters'

√Sur – Ena BKUP

If Sur – Ena Opr
sel N1-2 Heater Sur

N1_2_MDM_Survival_Heaters

'Command Status'

cmd Ena_BKUP

<Cmd Inv: MDM_N1_1_Ena_Bu_Srv_Htr – (M1TH96IM0273K)>

√Availbty – Ena BKUP

√Opr – Ena Opr

C&DH RECONFIGURE FOR NODE 1 MDMs

(GND/2A.2A - 3A/FIN A)

Page 3 of 7 pages

2.3 Reconfiguring N1-2 MDM EPS Remote Terminals

CRT

SM 200 APCU

√APCU1 OUT VOLTS RES LOW ≥ 121

PCS2

If APCU1 OUT VOLTS RES LOW ≥ 121

Node 1: C&DH: MDM N1-2

Primary NCS MDM Node1

sel LB Sys Lab – 2

sel RT Status

LB_SYS_LAB_RT_Status

cmd 18_RPCM_N13B_C RT Status – Enable Execute

cmd 19_RPCM_N13B_B RT Status – Enable Execute

cmd 20_RPCM_N13B_A RT Status – Enable Execute

<Cmd Inv: N1_2_MDM_Ena_RPCM_N13B_C –
(M1DD95SM1179K)>

<Cmd Inv: N1_2_MDM_Ena_RPCM_N13B_B –
(M1DD95SM1180K)>

<Cmd Inv: N1_2_MDM_Ena_RPCM_N13B_A –
(M1DD95SM1181K)>

LB_SYS_LAB_RT_Status

√RT Status 18, 19, 20 – ENA

cmd 18_RPCM_N13B_C RT FDIR Status – Enable FDIR Execute

cmd 19_RPCM_N13B_B RT FDIR Status – Enable FDIR Execute

cmd 20_RPCM_N13B_A RT FDIR Status – Enable FDIR Execute

<Cmd Inv: N1_2_MDM_Ena_FDIR_RPCM_N13B_C –
(M1DD95SM1342K)>

<Cmd Inv: N1_2_MDM_Ena_FDIR_RPCM_N13B_B –
(M1DD95SM1343K)>

<Cmd Inv: N1_2_MDM_Ena_FDIR_RPCM_N13B_A –
(M1DD95SM1344K)>

LB_SYS_LAB_RT_Status

√RT FDIR Status 18, 19, 20 – ENA

C&DH RECONFIGURE FOR NODE 1 MDMs

(GND/2A.2A - 3A/FIN A)

Page 4 of 7 pages

2.4 Resetting NCS Auto Retry Counter **On MCC-H GO**

PCS2

Node 1: C&DH: MDM N1-1

Secondary NCS MDM Node 1

sel MDM Utilities

If Auto Retry Counter - 1

cmd Reset Execute

<Cmd Inv: Sec_NCS_Rset_NCS_Retry_Cntr –
(M1SDD95SM2619K)>

√Auto Retry Counter – 0

2.5 Subsystem Reconfiguration

As required, reactivate the following MDM N1-2 equipment.

√**MCC-H** for the proper configuration

EQUIPMENT	PROCEDURE REFERENCE	COMMENTS
Node 1 Smoke Detector 2	NODE 1 SMOKE DETECTOR ACTIVATION/DEACTIVATION (SODF: ISS OPS: ECLSS)	Activate Node 1 Smoke Detector 2.
Node 1 Port Fwd IMV Fan	NODE 1 IMV FAN ACTIVATION/DEACTIVATION (SODF: ISS OPS: ECLSS)	Activate Node 1 Port Fwd IMV Fan only.
Node 1 Stbd Aft IMV Fan	NODE 1 IMV FAN ACTIVATION/DEACTIVATION (SODF: ISS OPS: ECLSS)	Activate Node 1 Stbd Aft IMV Fan only.
Node 1 Fwd Port IMV Valve	NODE 1 IMV VALVE RECONFIGURATION (SODF: ISS OPS: ECLSS)	Activate Node 1 Fwd Port IMV Valve only.
Node 1 Fwd Stbd IMV Valve	NODE 1 IMV VALVE RECONFIGURATION (SODF: ISS OPS: ECLSS)	Activate Node 1 Fwd Stbd IMV Valve only.

2.6 Resetting ACS Moding

If during Docked Ops, go to ACS PRE-DEPARTURE MODING for N1-2, all (SODF: ISS OPS: MCS).

3. RECONFIGURING THE NODE 1-1 MDM

3.1 Clearing MDM BST Error Latch

Perform NCS MDM BST CLEAR LATCHED DATA, for the Secondary N1-1 MDM, (SODF: GND: C&DH).

C&DH RECONFIGURE FOR NODE 1 MDMs

(GND/2A.2A - 3A/FIN A)

Page 5 of 7 pages

PCS2 3.2 Configuring MDM Heaters Controlled by the N1-1 MDM
Node 1: C&DH: MDM N1-1
Secondary NCS MDM Node 1
'RPCM N1RS1 A'

√RPC 5 Position – CI

If Open
sel RPC 5

RPCM_N1RS1_A_RPC_5

cmd Close

<Cmd Inv: RPCM_N1RS1_A_RPC_5_SDO_1A_N1_1_CI –
(M1PR95SM1329K)>

√RPC 5 Position – CI

'N1-1 Heaters'

√Opr – ENA OPR

'N1-2 Heaters'

√Sur – Ena BKUP

If Sur – Ena BKUP
sel N1-1 Heaters, Sur

N1_1_Survival Heater

cmd Enable BKUP

<Cmd Inv: N1_2_Srv_Htr_Ena_BU – (M1TH96IM0271K)>

√Availbty – Ena BKUP

CRT 3.3 Reconfiguring N1-1 MDM EPS Remote Terminals
SM 200 APCU

√APCU2 OUT VOLTS RES LOW ≥ 121

PCS2 If APCU2 OUT VOLTS RES LOW ≥ 121
Node 1: C&DH: MDM N1-1
Secondary NCS MDM Node1

sel LB Sys Lab – 1
sel RT Status

C&DH RECONFIGURE FOR NODE 1 MDMs

(GND/2A.2A - 3A/FIN A)

Page 6 of 7 pages

LB_SYS_LAB_RT_Status

cmd 18_RPCM_N14B_C RT Status – Enable Execute

cmd 19_RPCM_N14B_B RT Status – Enable Execute

cmd 20_RPCM_N14B_A RT Status – Enable Execute

<Cmd Inv: N1_1_MDM_Ena_RPCM_N14B_C –
(M1DD95SM1138K)>

<Cmd Inv: N1_1_MDM_Ena_RPCM_N14B_B –
(M1DD95SM1139K)>

<Cmd Inv: N1_1_MDM_Ena_RPCM_N14B_A –
(M1DD95SM1140K)>

LB_SYS_LAB_RT_Status

√RT Inhibited 18, 19, 20 – ENA

cmd 18_RPCM_N14B_C RT FDIR Status – Enable FDIR Execute

cmd 19_RPCM_N14B_B RT FDIR Status – Enable FDIR Execute

cmd 20_RPCM_N14B_A RT FDIR Status – Enable FDIR Execute

<Cmd Inv: N1_1_MDM_Ena_FDIR_RPCM_N14B_C –
(M1DD95SM1300K)>

<Cmd Inv: N1_1_MDM_Ena_FDIR_RPCM_N14B_B –
(M1DD95SM1301K)>

<Cmd Inv: N1_1_MDM_Ena_FDIR_RPCM_N14B_A –
(M1DD95SM1302K)>

LB_SYS_LAB_RT_Status

√RT FDIR Status 18, 19, 20 – ENA

3.4 Resetting NCS Auto Retry Counter

On MCC-H GO

PCS2

Node 1: C&DH: MDM N1-2

Primary NCS MDM Node 1

sel MDM Utilities

C&DH RECONFIGURE FOR NODE 1 MDMs

(GND/2A.2A - 3A/FIN A)

Page 7 of 7 pages

If Auto Retry Counter – 1
cmd Reset Execute

<Cmd Inv: Prim_NCS_Rset_NCS_Retry_Cntr –
(M1DD95SM2500K)>

√Auto Retry Counter – 0

3.5 Subsystem Reconfiguration

As required, reactivate the following MDM N1-1 equipment.

√**MCC-H** for proper configuration

EQUIPMENT	PROCEDURE REFERENCE	COMMENTS
Node 1 Cabin Fan	NODE 1 CABIN FAN ACTIVATION, (SODF: ISS OPS: ECLSS)	This procedure will start up the Cabin Fan and both Node 1 Smoke Detectors.
Node 1 Smoke Detector 1	NODE 1 SMOKE DETECTOR ACTIVATION (SODF: ISS OPS: ECLSS)	Execute only if Node 1 Cabin Fan Activation not performed.
Node 1 Smoke Detector 2	NODE 1 SMOKE DETECTOR ACTIVATION (SODF:ISS OPS: ECLSS)	Execute only if Node 1 Cabin Fan Activation not performed.
Node 1 Aft Port IMV Fan	NODE 1 IMV FAN ACTIVATION/ DEACTIVATION (SODF: ISS OPS: ECLSS)	Activate Node 1 Aft Port IMV Fan only.
Node 1 Aft Port IMV Valve	NODE 1 IMV VALVE RECONFIGURATION (SODF: ISS OPS: ECLSS)	Activate Node 1 Aft Port IMV Valve only.
Node 1 Aft Stbd IMV Valve	NODE 1 IMV VALVE RECONFIGURATION (SODF: ISS OPS: ECLSS)	Activate Node 1 Aft Stbd IMV Valve only.

3.6 Resetting ACS Moding

If during Docked Ops, perform ACS PRE-DEPARTURE MODING for N1-1, all (SODF: ISS OPS: MCS).

This Page Intentionally Blank

MCS PROCEDURES

This Page Intentionally Blank

ACS PRE-ARRIVAL MODING

(GND/3A/BAS A)

Page 1 of 3 pages

Identification Section:

Procedure Name: ACS Pre-Arrival Moding - Ground
Applicability: Arrival of Flights 2A.2, 3A, 4A, and 5A.
Frequency: This procedure is performed before entering the Prox Ops timeline.
Objective: To enable Arrival Response software and LEDs.
Description: The Arrival Response software acts upon the APAS Capture Long sensors at orbiter contact and cues the RS GNC to mode to Indicator (Drift). The LED Control software operates the ACS Moding Indicator light assemblies on the PMA to provide the orbiter crew with a visual indication of the RS GNC mode.

Crew Required: None
Power: N/A
Data: Required telemetry is given in the procedure.
Duration: Concurrent with integrated and arrival Prox Ops timeline.
Location: PMA2 for 2A.2 and 3A. PMA3 for 4A and 5A.
Parts: APAS docking mechanisms; Node 1 MDMs; RS segment MDMs, and Propulsion system.

Materials: N/A
Tools: N/A
Constraints: N/A
Assumptions: The orbiter maintains attitude control over mated stack.
Reference Materials: S684-10174 - 5/15/96; MDC 95H0250B 3/15/96 (Russian data), Pass2-100% 2A/3A Command and Telemetry file.

ACS PRE-ARRIVAL MODING

(GND/3A/BAS A)

Page 2 of 3 pages

1. ACS MODING PRE-ARRIVAL CONFIGURATION AND STATUS

PCS

MCS: ACS Moding

ACS Moding

'ACS Configuration'

Verify Moding Role Primary,Secondary NCS – Full

If Primary(Secondary) NCS Moding Role is not set to Full,
then the following commands should be sent:

sel Moding Role

Moding Role

cmd N1-2(N1-1) – Arm

Verify Arm Status Primary(Secondary) NCS – Arm

cmd N1-2(N1-1) – Full

Verify Moding Role Primary(Secondary) NCS – Full

Verify Arm Status Primary(Secondary) NCS – Disarm

Verify RS Mode Primary,Secondary NCS – Cntl

'Arrival'

Verify PMA2(PMA3) Arrival Response software Primary,Secondary NCS –
Inh

2. ACS MODING INDICATOR LIGHTS

NOTE

Each of the primary and secondary MDMs command one of the LED units (i.e., two units per PMA, four LEDs per unit). LED configurations: On - Active Attitude Control, Flash - Station in Free Drift, Off – LED Control Software is Inhibited or an MDM loss of comm situation has occurred.

PCS

MCS: ACS Moding

ACS Moding

'ACS Configuration'

sel LED Control SW

LED Control SW

'Primary NCS'

cmd Enable

√LED Control SW – Ena

Verify PMA2,PMA3 LED State – On

ACS PRE-ARRIVAL MODING

(GND/3A/BAS A)

Page 3 of 3 pages

'Secondary NCS'

cmd Enable

√LED Control SW – Ena

Verify PMA2,PMA3 LED State – On

3. ARRIVAL RESPONSE SOFTWARE FOR ACS MODING

ACS Moding

'Arrival'

sel PMA2(PMA3) Arrival Response SW

PMA2(PMA3) Arrival Response SW

'Primary NCS'

cmd Enable

Verify Arrival Response SW – Ena

'Secondary NCS'

cmd Enable

Verify Arrival Response SW – Ena

If Primary(Secondary) NCS Arrival Response SW needs to be inhibited (wave off, etc.), then the following commands should be sent:

sel PMA2(PMA3) Arrival Response SW

PMA2(PMA3) Arrival Response SW

'Primary NCS'('Secondary NCS')

cmd Arm

Verify Arm Status Primary(Secondary) NCS – Arm

cmd Inhibit

Verify Arrival Response SW Primary(Secondary) NCS – Inh

This Page Intentionally Blank

ACS ARRIVAL MODING

(GND/3A/BAS A)

Page 1 of 2 pages

Identification Section:

Procedure Name: ACS Arrival Moding - Ground
Applicability: Arrival of Flights 2A.2, 3A, 4A, and 5A.
Frequency: This procedure is performed during the Prox Ops timeline.
Objective: To monitor the ACS Moding function during orbiter arrival.
Description: The ACS Moding software declares an Orbiter Arrival Event based on APAS Capture Long sensor signals. The Arrival Event cues the RS GNC to mode to Indicator (Drift). The ACS Moding indicator lights provide orbiter crew with a visual indication of the RS GNC mode.

Crew Required: None
Power: N/A
Data: Required telemetry is given in the procedure.
Duration: Concurrent with integrated and arrival Prox Ops timeline.
Location: PMA2 for 2A.2 and 3A. PMA3 for 4A and 5A.
Parts: APAS docking mechanisms; Node 1 MDMs; RS segment MDMs, and Propulsion system.

Materials: N/A
Tools: N/A
Constraints: N/A
Assumptions: The orbiter maintains attitude control over mated stack.
Reference Materials: S684-10174 - 5/15/96; MDC 95H0250B 3/15/96 (Russian data), Pass2-100% 2A/3A Command and Telemetry file.

ACS ARRIVAL MODING

(GND/3A/BAS A)

Page 2 of 2 pages

1. VERIFYING ACS MODING PRE-ARRIVAL CONFIGURATION AND STATUS

PCS

MCS: ACS Moding

ACS Moding

'ACS Configuration'

Verify Moding Role Primary,Secondary NCS – Full

Verify RS Mode Primary,Secondary NCS – Cntl

√LED Control Software Primary,Secondary NCS – Ena

Verify PMA2,PMA3 LED State Primary,Secondary NCS – On

'Arrival'

√PMA2(PMA3) Arrival Response SW Primary,Secondary NCS – Ena

2. ACS MODING AT ORBITER DOCKING

Perform STATION-ORBITER DOCKING SCRIPT, all (SODF: GND: MCS), then proceed.

3. STATION ACS MODING POST-DOCKING CONFIGURATION

PCS

MCS: ACS Moding

ACS Moding

'Arrival'

Verify PMA2(PMA3) Capture Long Primary,Secondary NCS – X

Verify Arrival Event Primary,Secondary NCS – X

'ACS Configuration'

Verify RS Mode Primary,Secondary NCS – Drift

Verify PMA2,PMA3 LED State Primary,Secondary NCS – Flash

NOTE

The following signals nominally may take up to 13 minutes to occur before hard mate is completed.

'Departure'

Verify PMA2(PMA3) Interface Sealed Primary,Secondary NCS – X

Verify PMA2(PMA3) Separation Primary,Secondary NCS – blank

ACS DEPARTURE MODING

(GND/3A/FIN)

Page 1 of 2 pages

- PCS 1. VERIFYING ACS MODING SOFTWARE CONFIGURATION |
- MCS:ACS Moding
ACS Moding
'Departure'

Verify PMA2(PMA3) Interface Sealed Primary, Secondary NCS – X
Verify PMA2(PMA3) Separation Primary, Secondary NCS – blank
Verify PMA2(PMA3) Departure Response SW Primary, Secondary NCS –
Ena
Verify Back Off Time Primary, Secondary NCS: 250 (seconds) |
Verify Time Since Separation Primary, Secondary NCS: 0
Verify Departure Event Primary, Secondary NCS – blank

2. MONITORING NCS SEPARATION SIGNALS AND VERIFICATION OF ORBITER DEPARTURE AND POST SEPARATION LED MODE CHANGE |

If the Primary(Secondary) Time Since Separation is observed to be incrementing any time prior to planned departure, IMMEDIATE ACTION IS REQUIRED.

sel Moding Role

Moding Role

cmd N1-2(N1-1) – Arm

Verify Arm Status Primary(Secondary) NCS – Arm

cmd N1-2(N1-1) – Off

Verify Moding Role Primary(Secondary) NCS – Off

Verify Arm Status Primary(Secondary) NCS – Disarm

NOTE

1. For flights prior to onboard crew, orbiter monitoring of Station telemetry is discontinued when orbiter OIU is disconnected.
2. The Time Since Separation counter is initiated when Separation is true (X) and Interface Sealed is false (blank).
3. The Departure Event is set when the Time Since Separation equals the set Back Off Time. When the SM receives the Departure Event request, it will resume active attitude control.

'Departure'

Monitor the following during vehicle separation.

ACS DEPARTURE MODING

(GND/3A/FIN)

Page 2 of 2 pages

Verify PMA2(PMA3) Interface Sealed Primary, Secondary NCS – blank
Verify PMA2(PMA3) Separation Primary,Secondary NCS – X
Verify Time Since Separation Primary,Secondary NCS – <Increasing> |

When Time Since Separation equals Back Off Time:

Verify Departure Event Primary,Secondary NCS – X |

3. VERIFICATION OF RUSSIAN SEGMENT ATTITUDE CONTROL AND LED STATUS |

PCS

MCS: ACS Moding

'ACS Configuration'

Verify RS Mode Primary,Secondary NCS – Cntl

Verify PMA2,PMA3 LED State Primary,Secondary NCS – On

PCS

SM MCS

Verify RS GNC Mode – Thrusters

ACS POST DEPARTURE MODING

(GND/3A/BAS A)

Page 1 of 2 pages

Identification Section:

Procedure Name: ACS Post Departure Moding - Ground
Applicability: Departure of Flights 2A.2, 3A, and 4A.
Frequency: This procedure is performed after the departure sequence.
Objective: Inhibit the Station ACS Moding indicator lights and Departure Response software.
Description: The ACS Moding indicator lights (LEDs) will be powered off. Then the Departure Response software, which monitors the APAS Interface Sealed and Undocking Complete sensors, will be inhibited.
Crew Required: None
Power: N/A
Data: Required telemetry is given in the procedure.
Duration: Concurrent with integrated and departure Prox Ops timeline.
Location: PMA2 for 2A.2 and 3A. PMA3 for 4A.
Parts: APAS docking mechanisms; Node 1 MDMs; RS segment MDMs, and Propulsion system.
Materials: N/A
Tools: N/A
Constraints: None
Assumptions: N/A
Reference Materials: S684-10174 - 5/15/96; MDC 95H0250B 3/15/96 (Russian data), PAS2-100% 2A/3A, Engineering release cycle, and Standard out Command and Telemetry files. ACS Moding Display Revision 3A-1.

ACS POST DEPARTURE MODING

(GND/3A/BAS A)

Page 2 of 2 pages

- PCS
1. ACS MODING INDICATOR LIGHTS
MCS: ACS Moding
 ACS Moding
'ACS Configuration'

sel LED Control SW

 LED Control SW
'Primary NCS'

cmd Inhibit
√LED Control SW – Inh
Verify PMA2,PMA3 LED State – Off

'Secondary NCS'

cmd Inhibit
√LED Control SW – Inh
Verify PMA2,PMA3 LED State – Off
 2. DEPARTURE RESPONSE
 ACS Moding
'Departure'

sel PMA2(PMA3) Departure Response SW

 PMA2(PMA3) Departure Response SW
'Primary NCS'

cmd Inhibit
Verify Departure Response SW – Inh
Verify Arm Status – Disarm

'Secondary NCS'

cmd Inhibit
Verify Departure Response SW – Inh
Verify Arm Status – Disarm

 ACS Moding
'Departure'

Verify Departure Event Primary,Secondary NCS – blank

S&M PROCEDURES

S&M

This Page Intentionally Blank

NODE 1 FORWARD CBM CPA CHECKOUT

(GND/3A/BAS A)

Page 1 of 18 pages

OBJECTIVE:

Verify CBM full functionality after the reinstallation of CBM hardware or as a flight test.

LOCATION:

NOD1/MCC-H

DURATION:

1 hour 15 minutes

REFERENCED PROCEDURE(S):

None

NOTE

1. Forward CBM connectivity is as follows:
CB GNC 1 A = CPA 1
 B = CPA 4
CB GNC 2 A = CPA 2
 B = CPA 3
2. Where CDDT HTMLs are used to command, Command Inventory command ops names and CI PUIs are listed beneath each command in parentheses and italics.

1. VERIFYING POWER CONFIGURATION

N1_Fwd_CBM_Power_Data

'RPCM N13B C'

√Integ Counter – <incrementing>

'RPCM N14B A'

√Integ Counter – <incrementing>

'APCU-1'

√Volts Hi (Res) >122 volts

'APCU-2'

√Volts Hi (Res) >122 volts

2. VERIFYING MDM CONFIGURATION

N1_Fwd_CBM_Power_Data

'Primary MDM'

√MDM ID – N1-2

√Frame Count – <incrementing>

'Secondary MDM'

√MDM ID – N1-1

√Frame Count – <incrementing>

√CB GNC N1-1 Bus Channel

Record A or B _____

√CB GNC N1-2 Bus Channel

Record A or B _____

3. ENABLING PRIMARY RPCS

sel N1 Forward CBM Checkout

cmd RPCM N13B-C RPC [X] CPA [Y] Pri Close – Enable |

where [X] =

[Y] =

<Cmd Inv: RPCM_N13B_C_RPC_[X]_CBM_N1_Fwd_Pri_[Y]_Cl-
Enable – (M1PR95SM1147K, 1148K, 1149K, 1150K)>

'RPCM N13B C'

√RPC [X] CI – Ena

Repeat

4. ENABLING SECONDARY RPCS

CBM_Cmds.msk

sel N1 Forward CBM Checkout

N1 Forward CBM Checkout

cmd RPCM N14B-A RPC [X] CPA [Y] Sec Close – Enable |

where [X] = 02 03 14 15

[Y] = 1 2 3 4

<Cmd Inv: RPCM_N14B_A_RPC_[X]_CBM_N1_Fwd_Sec_[Y]_Cl-
Enable – (M1PR95SM1200K, 1201K, 1212K, 1213K)>

N1_Fwd_CBM_Power_Data

'RPCM N14B A'

√RPC [X] Cl – Ena

Repeat

5. CLOSING SECONDARY RPCS

CBM_Cmds.msk

sel N1 Forward CBM Checkout

N1 Forward CBM Checkout

cmd RPCM N14B-A RPC [X] CPA [Y] Sec Close |

where [X] = 02 03 14 15

[Y] = 1 2 3 4

<Cmd Inv: RPCM_N14B_A_RPC_[X]_CBM_N1_Fwd_Sec_[Y]_Cl-
(M1PR95SM1164K, 1165K, 1176K, 1177K)>

N1_Fwd_CBM_Power_Data

'RPCM N14B A'

√RPC [X] Posn – Cl

Repeat

NODE 1 FORWARD CBM CPA CHECKOUT

(GND/3A/BAS A)

Page 4 of 18 pages

6. ACTIVATING FORWARD CBM PRIMARY MASTER CONTROLLER

N1 Forward CBM Checkout

cmd Activate Primary Master **Execute**

<Cmd Inv: CBM_Activate_N1_Fwd_Pri_Master – (M1MC95SM1160K)>

Wait 20 seconds, then:

N1_Fwd_CBM_Power_Data

'CBM Status'

√Mode – Activated
√Master – Primary
√CPA – Record # _____
√Comm Error – blank

Node_1_CBM.msk

√Master Cmd Status – Complete
√Active BIT Error – blank
√Background BIT Error – blank
√Master Cmd Error – blank
√Slave Cmd Error – blank
√485 Timeout – blank
√Command Rejected – blank
√485 Channel (twenty) – B

7. INITIALIZING CONTROLLER POSITIONS ZERO

N1 Forward CBM Checkout

cmd Set All Zero Ch B **Execute**

<Cmd Inv: CBM_Set_All_Posns_To_Zero_Ch_B – (M1MC96IM0002K)>

Node_1_CBM.msk

√Master Cmd Status – Complete

8. VERIFYING RS-485 COMM STATUS

NOTE

CBM Active BIT may have to be commanded multiple times to clear MSBDs.

Node_1_CBM.msk

√Cmd Code (twenty) – RELD
√Cmd Stat (twenty) – CPLT

If any Cmd Stat - MSBD

N1 Forward CBM Checkout

cmd CBM Active BIT Execute

<Cmd Inv: CBM_Act_Built_In_Test – (M1MC95SM1027K)>

Node_1_CBM.msk

√Confirmation Request – Built-in Test

N1 Forward CBM Checkout

cmd CBM Active BIT Execute

<Cmd Inv: CBM_Act_Built_In_Test – (M1MC95SM1027K)>

Wait 15 seconds, then:

Node_1_CBM.msk

√Master Cmd Status – Complete

√Active BIT Error – blank

√Cmd Code (twenty) – BIT

√Cmd Stat (twenty) – CPLT

9. VERIFING CONTROLLER POSITIONS ZERO

Node_1_CBM.msk

√Position (twenty): 0 rev | deg

If any position ≠ 0 rev | deg

N1 Forward CBM Checkout

cmd Set All Zero Ch B Execute

<Cmd Inv: CBM_Set_All_Posns_To_Zero_Ch_B –
(M1MC96IM0002K)>

Node_1_CBM.msk

√Master Cmd Status – Complete

√Background BIT Error – blank

√Master Cmd Error – blank

√Slave Cmd Error – blank

√Cmd Code (twenty) – RELD

√Cmd Stat (twenty) – CPLT

√Position (twenty): 0 rev | deg

10. TESTING BOLT DRIVE

N1 Forward CBM Checkout

cmd DBBoltck Nominal **Execute**

<Cmd Inv: CBM_DBBoltck_Nominal – (M1MC95SM1331K)>

Node_1_CBM.msk

√Confirmation Request – DBBoltck

N1 Forward CBM Checkout

cmd Confirm Cmd **Execute**

<Cmd Inv: CBM_Confirm_Cmd – (M1MC95SM1470K)>

Wait 30 seconds, then:

Node_1_CBM.msk

√Master Cmd Status – Complete

√Bolt Cmd Code (sixteen) – DBCK

√Bolt Cmd Stat (sixteen) – CPLT

√Bolt Position (sixteen): 50 --- 51 rev

11. DEACTIVATING FORWARD CBM MASTER CONTROLLER

N1 Forward CBM Checkout

cmd Deactivate CBM **Execute**

<Cmd Inv: CBM_Deactivate_N1_Fwd – (M1MC95SM1006K)>

N1_Fwd_CBM_Power_Data

'CBM Status'

√Mode – Deactivated

12. OPENING SECONDARY RPCS

cmd RPCM N14B-A RPC [X] CPA [Y] Sec Open |

where [X] =

[Y] =

<Cmd Inv: RPCM_N14B_A_RPC_[X]_CBM_N1_Fwd_Sec_[Y]_Op –
(M1PR95SM1812K, 1813K, 18624K, 1825K)>

'RPCM N14B A'

√RPC [X] Posn – Op

Repeat

13. CLOSING PRIMARY RPCS

cmd RPCM N13B-C RPC [X] CPA [Y] Pri Close |

where [X] =

[Y] =

<Cmd Inv: RPCM_N13B_C_RPC_[X]_CBM_N1_Fwd_Pri_[Y]_Cl –
(M1PR95SM1111K, 1112K, 1113K, 1114K)>

'RPCM N13B C'

√RPC [X] Posn – Cl

Repeat

14. ACTIVATING FORWARD CBM SECONDARY MASTER CONTROLLER

cmd Activate Secondary Master **Execute**

<Cmd Inv: CBM_Activate_N1_Fwd_Sec_Master – (M1MC95SM1161K)>

Wait 20 seconds, then:

'CBM Status'

√Mode – Activated
√Master – Secondary
√CPA – Record # _____
√Comm Error – blank

Node_1_CBM.msk

√Master Cmd Status – Complete
√Active BIT Error – blank
√Background BIT Error – blank
√Master Cmd Error – blank
√Slave Cmd Error – blank
√485 Timeout – blank
√Command Rejected – blank
√485 Ch (twenty) – B

15. [SWITCHING RS-485 BUS TO CHANNEL A](#)

N1 Forward CBM Checkout

cmd Set Last State to Stop Ch A Execute

<Cmd Inv: CBM_Set_Last_State_To_Stop_Ch_A –
(M1MC95SM1491K)>

Node_1_CBM.msk

√Master Cmd Status – Complete
√485 Ch (twenty) – A

16. [SETTING CONTROLLER POSITIONS ZERO](#)

N1 Forward CBM Checkout

cmd Set All Zero Ch A Execute

<Cmd Inv: CBM_Set_All_Posns_To_Zero_Ch_A – (M1MC96IM0004K)>

Node_1_CBM.msk

√Master Cmd Status – Complete
√485 Ch (twenty) – A

17. [VERIFYING RS-485 COMM STATUS](#)

NOTE
CBM active BIT may have to be commanded
multiple times to clear MSBDs.

Node_1_CBM.msk

√Cmd Code (twenty) – RELD
√Cmd Stat (twenty) – CPLT

NODE 1 FORWARD CBM CPA CHECKOUT

(GND/3A/BAS A)

Page 9 of 18 pages

If any Cmd Stat - MSBD

N1 Forward CBM Checkout

cmd CBM Active BIT Execute

<Cmd Inv: CBM_Act_Built_In_Test – (M1MC95SM1027K)>

Node_1_CBM.msk

√Confirmation Request – Built-in Test

N1 Forward CBM Checkout

cmd CBM Active BIT Execute

<Cmd Inv: CBM_Act_Built_In_Test – (M1MC95SM1027K)>

Wait 15 seconds, then:

Node_1_CBM.msk

√Master Cmd Status – Complete

√Active BIT Error – blank

√Cmd Code (twenty) – BIT

√Cmd Stat (twenty) – CPLT

18. VERIFYING CONTROLLER POSITIONS ZERO

Node_1_CBM.msk

√Position (twenty): 0 rev | deg

If any position ? 0 rev | deg

N1 Forward CBM Checkout

cmd Set All Zero Ch A Execute

<Cmd Inv: CBM_Set_All_Posns_To_Zero_Ch_A – (M1MC96IM0004K)>

Node_1_CBM.msk

√Master Cmd Status – Complete

√Background BIT Error – blank

√Master Cmd Error – blank

√Slave Cmd Error – blank

√Cmd Code (twenty) – RELD

√Cmd Stat (twenty) – CPLT

√Position (twenty): 0 rev | deg

19. DEPLOYING LATCH 1 TO 210

cmd Deploy Latch 1 to 210 **Execute**

<Cmd Inv: CBM_Deploy_Latch_1_to_210_Degrees –
(M1MC96IM0027K)>

√Confirmation Request – Deploy

cmd Confirm Cmd **Execute**

<Cmd Inv: CBM_Confirm_Command – (M1MC95SM1470K)>

Wait 90 seconds, then:

- √Master Cmd Status – Failed
- √Latch 1 Cmd Code – DPLY
- √Latch 1 Cmd Stat – BIND
- √Latch 1 Position: 200 --- 210 deg
- √Latch 1 Capture Switch CI – X

20. DEPLOYING LATCH 2 TO 210

cmd Deploy Latch 2 to 210 **Execute**

<Cmd Inv: CBM_Deploy_Latch_2_to_210_Degrees –
(M1MC96IM0028K)>

√Confirmation Request – Deploy

cmd Confirm Cmd **Execute**

<Cmd Inv: CBM_Confirm_Command – (M1MC95SM1470K)>

Wait 90 seconds, then:

Node_1_CBM.msk

- √Master Cmd Status – Failed
- √Latch 2 Cmd Code – DPLY
- √Latch 2 Cmd Stat – CPLT
- √Latch 2 Position: 200 --- 210 deg
- √Latch 2 Capture Switch CI – X

21. DEPLOYING LATCH 3 TO 210

N1 Forward CBM Checkout

cmd Deploy Latch 3 to 210 Execute

<Cmd Inv: CBM_Deploy_Latch_3_to_210_Degrees –
(M1MC96IM0029K)>

Node_1_CBM.msk

- √Confirmation Request – Deploy

N1 Forward CBM Checkout

cmd Confirm Cmd Execute

<Cmd Inv: CBM_Confirm_Command – (M1MC95SM1470K)>

Wait 90 seconds, then:

Node_1_CBM.msk

- √Master Cmd Status – Failed
- √Latch 3 Cmd Code – DPLY
- √Latch 3 Cmd Stat – BIND
- √Latch 3 Position: 200 --- 210 deg
- √Latch 3 Capture Switch CI – X

22. DEPLOYING LATCH 4 TO 210

N1 Forward CBM Checkout

cmd Deploy Latch 4 to 210 Execute

<Cmd Inv: CBM_Deploy_Latch_4_to_210_Degrees –
(M1MC96IM0030K)>

Node_1_CBM.msk

- √Confirmation Request – Deploy

N1 Forward CBM Checkout

cmd Confirm Cmd Execute

<Cmd Inv: CBM_Confirm_Command – (M1MC95SM1470K)>

Wait 90 seconds, then:

Node_1_CBM.msk

√Master Cmd Status – Failed
√Latch 4 Cmd Code – DPLY
√Latch 4 Cmd Stat – BIND
√Latch 4 Position: 200 --- 210 deg
√Latch 4 Capture Switch CI – X

23. CLEARING LATCH BIND INDICATIONS

NOTE

Stop command may nominally need to be issued multiple times to clear binding indications.

N1 Forward CBM Checkout

cmd Stop Execute

<Cmd Inv: CBM_Stop_All_Controllers – (M1MC95SM1435K)>

Node_1_CBM.msk

√Master Cmd Status – Complete
√Latch Cmd Code (four) – STOP
√Latch Cmd Stat (four) – CPLT

24. SETTING BOLT/LATCH START POSITIONS

N1 Forward CBM Checkout

cmd Set Deberthing Start Posns Ch A Execute

<Cmd Inv: CBM_Set Deberthing_Start_Posns_Ch A – (M1MC96IM0024K)>

Node_1_CBM.msk

NODE 1 FORWARD CBM CPA CHECKOUT

(GND/3A/BAS A)

Page 13 of 18 pages

- √Master Cmd Status – Complete
- √Cmd Code (twenty) – RELD
- √Cmd Stat (twenty) – CPLT
- √Bolt Position (sixteen): 51 rev
- √Latch Position (four): 202 deg

25. [MOVING LATCHES TO CAPTURE POSITIONS](#)

cmd Capture for Deberth **Execute**

<Cmd Inv: CBM_Capture_For_Deberth – (M1MC96IM0033K)>

- √Confirmation Request – Capture

cmd Confirm Cmd **Execute**

<Cmd Inv: CBM_Confirm_Cmd – (M1MC95SM1470K)>

Wait 90 seconds, then:

- √Master Cmd Status – Complete
- √Latch Cmd Code (four) – DPLY
- √Latch Cmd Stat (four) – CPLT
- √Latch Position (four): 200 --- 210 deg
- √Latch Capture Switch CI (four) – X

26. [CLOSING LATCHES](#)

cmd Close Nominal **Execute**

<Cmd Inv: CBM_Close_Nominal – (M1MC96IM0036K)>

- √Confirmation Request – Close

cmd Confirm Cmd **Execute**

<Cmd Inv: CBM_Confirm_Cmd – (M1MC95SM1470K)>

Wait 90 seconds, then:

Node_1_CBM.msk

- √Master Cmd Status – Complete
- √Latch Cmd Code (four) – CLOS
- √Latch Cmd Stat (four) – CPLT
- √Latch Position (four): 0 --- 1 deg

27. DEACTIVATING FORWARD CBM MASTER CONTROLLER

N1 Forward CBM Checkout

cmd Deactivate CBM Execute

<Cmd Inv: CBM_Deactivate_N1_Fwd – (M1MC95SM1006K)>

N1_Fwd_CBM_Power_Data

'CBM Status'

- √Mode – Deactivated

28. PERFORMING CB-GNC N1-1 BUS CHANNEL SWITCH (C&DH)

NOTE

Steps 28 and 29 check out remaining CBM master controllers and 1553 channels.

- √CB-GNC N1-1 Bus Channel

Record A or B _____

If Bus Channel recorded was A, then:

<Cmd Inv: N1_1_MDM_CB_GNC_1_Sel_Ch_B – (M1DD95SM1396K)>

- √CB-GNC N1-1 Bus Channel – B

If Bus Channel recorded was B, then:

<Cmd Inv: N1_1_MDM_CB_GNC_1_Sel_Ch_A – (M1DD95SM1395K)>

- √CB-GNC N1-1 Bus Channel – A

NODE 1 FORWARD CBM CPA CHECKOUT

(GND/3A/BAS A)

Page 15 of 18 pages

29. PERFORMING CB-GNC N1-2 BUS CHANNEL SWITCH (C&DH)

√CB-GNC N1-2 Bus Channel

Record A or B _____

If Bus Channel recorded was A, then:

<Cmd Inv: N1_2_MDM_CB_GNC_2_Sel_Ch_B –
(M1DD95SM1402K)>

√CB-GNC N1-2 Bus Channel – B

If Bus Channel recorded was B, then:

<Cmd Inv: N1_2_MDM_CB_GNC_2_Sel_Ch_A –
(M1DD95SM1401K)>

√CB-GNC N1-2 Bus Channel – A

30. CHECKING OUT CBM PRIMARY MASTER CONTROLLER, OPPOSITE CHANNEL

N1 Forward CBM Checkout

cmd Activate Primary Master Execute

<Cmd Inv: CBM_Activate_N1_Fwd_Pri_Master – (M1MC95SM1160K)>

Wait 20 seconds, then:

N1_Fwd_CBM_Power_Data

'CBM Status'

√Mode – Activated

√Master – Primary

√CPA – Record # _____

√Comm Error – blank

Node_1_CBM.msk

√Master Cmd Status – Complete

√Active BIT Error – blank

√Background BIT Error – blank

√Master Cmd Error – blank

√Slave Cmd Error – blank

√485 Timeout – blank

√Command Rejected – blank

√485 Ch (twenty) – B

31. CHECKING OUT CBM SECONDARY MASTER CONTROLLER,
OPPOSITE CHANNEL

N1 Forward CBM Checkout

cmd Activate Secondary Master **Execute**

<Cmd Inv: CBM_Activate_N1_Fwd_Sec_Master – (M1MC95SM1161K)>

Wait 20 seconds, then:

N1_Fwd_CBM_Power_Data

'CBM Status'

√Mode – Activated
√Master – Secondary
√CPA – Record # _____
√Comm Error – blank

Node_1_CBM.msk

√Master Cmd Status – Complete
√Active BIT Error – blank
√Background BIT Error – blank
√Master Cmd Error – blank
√Slave Cmd Error – blank
√485 Timeout – blank
√Command Rejected – blank
√485 Ch (sixteen bolts, four latches) – B

32. DEACTIVATING FORWARD CBM MASTER CONTROLLER

N1 Forward CBM Checkout

cmd Deactivate CBM **Execute**

<Cmd Inv: CBM_Deactivate_N1_Fwd – (M1MC95SM1006K)>

N1_Fwd_CBM_Power_Data

'CBM Status'

√Mode – Deactivated

33. OPENING PRIMARY RPCs

N1 Forward CBM Checkout

cmd RPCM N13B-C RPC [X] CPA [Y] Pri Open |

where [X] =

[Y] =

<Cmd Inv: RPCM_N13B_C_RPC_[X]_CBM_N1_Fwd_Pri_[Y]_Op –
(M1PR95SM1759K, 1760K, 1761K, 1762K)>

N1_Fwd_CBM_Power_Data
'RPCM N13B C'

√RPC [X] Posn – Op

Repeat

34. INHIBITING PRIMARY RPCs

cmd RPCM_N13B_C_RPC_[X]_CBM_N1_Fwd_Pri_[Y]_CI_Inhib_On |

where [X] =

[Y] =

<Cmd Inv: RPCM_N13B_C_RPC_[X]_CBM_N1_Fwd_Pri_[Y]_CI_Inhib_On –
(M1PR95SM1129K, 1130K, 1131K, 1132K)>

N1_Fwd_CBM_Power_Data
'RPCM N13B C'

√RPC [X] CI – Inh

Repeat

35. INHIBITING SECONDARY RPCS

cmd RPCM_N14B_A_RPC_[X]_CBM_N1_Fwd_Sec_[Y]_CI_Inhib_On |

where [X] =

[Y] =

<Cmd Inv: RPCM_N14B_A_RPC_[X]_CBM_N1_Fwd_Sec_[Y]_CI_Inhib_On – M1PR95SM1182K, 1183K, 1194K, 1195K>

'RPCM N14B A'

√RPC [X] CI – Inh

Repeat

TCS PROCEDURES

TCS

This Page Intentionally Blank

PMA 3 HEATER CHECKOUT

(GND/3A/FIN)

Page 1 of 4 pages

I

Identification Section:

Procedure Name: PMA3 Heater Checkout
Applicability: 3A
Frequency: Rare
Objective: To verify the PMA 3 shell heater functionality.
Description: This procedure verifies the PMA 3 shell heater functionality.
VSS2 version 14.
Crew Required: Ground
Power: TBD
Data: Cyclic Telemetry
Duration: 30 minutes
Location: **MCC-H**
Parts: None
Materials: None
Tools: None
Constraints: None
Reference Materials: Node Control Software SRS
Assumptions: None
Definitions: X = Heater Designator (i.e., 1B)
Y = the RPC corresponding to the heater you are enabling (i.e., 2)

PMA 3 HEATER CHECKOUT

(GND/3A/FIN)

Page 2 of 4 pages

1. RECORDING AVAILABILITY OF HEATER TO BE CHECKED OUT

Prior to the execution of this procedure, the **MCC-H** will have built the appropriate commands from the Command Inventory interface using the following procedures:

PMA 3 HEATER INHIBIT TEMPLATE COMMAND BUILD: TCS
CONSOLE HANDBOOK

PMA 3 HEATER ENABLE TEMPLATE COMMAND BUILD: TCS
CONSOLE HANDBOOK

SHELL HEATER - UPDATE TEMPERATURE SENSOR SETPOINTS:
GND HANDBOOK: TCS

All commands should be sent from the Command Inventory interface. CDDT/PCS should not be used for this procedure due to identified display problems.

Availability = _____

Failure Upper Limit, degC: _____

Upper Setpoint, degC: _____

Lower Setpoint, degC: _____

Failure Lower Limit, degC: _____

Cyclic Load Delta, degC: _____

2. INHIBITING HEATER TO BE CHECKED OUT

<Cmd Inv: PMA3 Htr[X] Inh Fixed>

where X = heater designator (i.e., 1B)

√Availability – Inh

3. UPDATING HEATER SETPOINTS

NOTE

The temperature of the heater to be checked out must be below the lower setpoint.

<Cmd Inv: Update PMA3 Htr[X] Temp_Snsr_Setpoints_[Descriptor]

Uplink Crit 4>

where X = heater designator (i.e., 1B)

Verify new setpoints are received onboard.

4. ENABLING HEATER TO BE CHECKED OUT

PCS

RPCM N1RS2 B RPC Y where Y - the RPC corresponding to the heater you are enabling (i.e., 2)

√Close Cmd – Ena

PMA 3 HEATER CHECKOUT

(GND/3A/FIN)

Page 3 of 4 pages

<Cmd Inv: PMA3 Htr[X] Ena Opr Uplink Crit 4>

where X = heater designator (i.e., 1B)

√Availability – Ena Opr

5. VERIFYING HEATER TURNED ON

Verify PMA3 Htr[X] Cmd Stat – On

Verify PMA3 Htr[X] RPC Posn – Closed

where X = heater designator (i.e., 1B)

Wait 30 minutes.

NOTE

Temperature and RPCM Current changes will be plotted to determine successful heater operation.

6. INHIBITING HEATER

<Cmd Inv: PMA3 Htr[X] Inh Fixed>

where X = heater designator (i.e., 1B)

√Availability – Inh

7. RETURNING HEATER SETPOINTS TO ORIGINAL VALUES

<Cmd Inv: Update PMA3 Htr[X] Temp Snsr Setpoints [Descriptor] Uplink Crit 4>

where X = heater designator (i.e., 1B)

Verify new setpoints are received onboard.

8. RETURNING HEATER AVAILABILITY TO ORIGINAL VALUE

<Cmd Inv: PMA3 Htr[X] Value in Step 1 Uplink Crit 4>

where X = heater designator (i.e., 1B)

9. MODIFYING SETPOINTS FOR PMA 3 HEATERS 5A AND 5B

Steps 9 and 10 should not be performed until all 10 PMA 3 heaters have been checked out per steps 1 through 8.

Modify setpoints for PMA3 Htr 5A and PMA3 Htr 5B to the values listed below.

PMA 3 HEATER CHECKOUT

(GND/3A/FIN)

Page 4 of 4 pages

Specific values to be entered in the template command for both PMA3 Htr 5A and PMA3 Htr 5B are listed below. Values are provided for each of the five items in the template: Upper Setpoint, Failure Upper Limit, Lower Setpoint, Failure Lower Limit, and Cyclic Load Delta.

Failure Upper Limit, degC: 45

Upper Setpoint, degC: -28

Lower Setpoint, degC: -33

Failure Lower Limit, degC: -45

Cyclic Load Delta, degC: 2.24

<Cmd Inv: Update PMA3 Htr[x] Temp Snsr Setpoints [Descriptor]> Uplink
Crit 4

where X = heater designator (i.e., 1B)

Verify setpoints are received onboard.

10. ENABLING TO OPERATE PMA3 HEATERS 5A AND 5B

PCS

<Cmd Inv: PMA3 Htr5A Ena Opr> Uplink Crit 4

√Availability – Ena Opr

<Cmd Inv: PMA3 Htr5B Ena Opr> Uplink Crit 4

√Availability – Ena Opr